

Lecture # 11.2 CHE331A

- Basics of reactions and ideal reactors
- Design/Analysis of CSTRs, PFRs, PBRs, Batch and Semi-batch in terms of conversions and molar flow rates or concentrations
- Collection and Analysis of Rate Data – Other methods and differential reactors

GOUTAM DEO

CHEMICAL ENGINEERING DEPARTMENT

IIT KANPUR

Non-linear Regression


$$-r_A = k \cdot C_A^\alpha$$

$$\sigma^2 = \frac{s^2}{N - K} = \sum_{i=1}^N \frac{(y_{im} - y_{ic})^2}{N - K}$$

$$\sigma^2 = \sum_{i=1}^{10} \frac{(C_{A,im} - C_{A,ic})^2}{10 - 2}$$

$$\sigma^2 = \sum_{i=1}^{10} \frac{(t_{im} - t_{ic})^2}{10 - 2}$$

Finding the best value of α and k



Other methods to determine rate law parameters: Method of Initial Rates

- ▶ **Method of Initial Rates:** rates are determined by using initial conc
 - Useful for reversible reactions $A \rightleftharpoons B$
$$-r_A = k_A C_A^\alpha - k_B C_B^\beta$$
- ▶ Several reactions are carried out with different C_{A0} and with $C_{B0} = 0$, $-r_{A0}$ is determined, e.g., by numerical differentiation
 - Use plot of $\ln(-r_{A0})$ vs $\ln(C_{A0})$ to determine order with respect to A
- ▶ Similarly, reactions are carried out with different C_{B0} and with $C_{A0} = 0$, $-r_{B0}$ is determined, e.g., by numerical differentiation
 - Use plot of $\ln(-r_{B0})$ vs $\ln(C_{B0})$ to determine order with respect to



Other methods to determine rate law parameters: Methods of Half-Lives

- ▶ **Method of Half-Lives:** Half-life of a reaction is defined as the time taken to reduce the conc of the reactant to half of its initial value
 - Used for irreversible reactions $A \rightarrow Products$ $-r_A = k_A C_A^\alpha$
- ▶ Combining the mole balance with stoichiometry $\frac{dC_A}{dt} = r_A = -k \cdot C_A^\alpha$
- ▶ Integrating with known initial conditions: $t = \frac{1}{k(\alpha-1)} \left(\frac{1}{C_A^{\alpha-1}} - \frac{1}{C_{A0}^{\alpha-1}} \right)$
- ▶ $t = \frac{1}{k(\alpha-1)C_{A0}^{\alpha-1}} \left[\left(\frac{C_{A0}}{C_A} \right)^{\alpha-1} - 1 \right]$ and with $C_A = 0.5C_{A0}$ at $t = t_{1/2}$
$$t_{1/2} = \frac{2^{\alpha-1} - 1}{k(\alpha-1)} \left(\frac{1}{C_{A0}^{\alpha-1}} \right)$$



Methods of Half-Lives continued

► $t_{1/2} = \frac{2^{\alpha-1}-1}{k(\alpha-1)} \left(\frac{1}{C_{A0}^{\alpha-1}} \right)$ using several C_{A0} then $t_{1/2}$ can be measured


► Plot $\ln(t_{1/2})$ vs $\ln(C_{A0})$ and slope = $1 - \alpha$

Slope = -0.42, $\alpha = 1.42$

Choosing C_{A0} at $t_{1/2}$

$$k = \frac{2^{1.42-1}-1}{t_{1/2}(1.12-1)} \left(\frac{1}{C_{A0}^{1.42-1}} \right)$$

C_{A0}	$t(1/2), s$
10	60
6	80
2	120



► In general, the time required for the concentration to drop to $1/n$ of the initial value, i.e., $C_A = \frac{1}{n} C_{A0}$ at $t = t_{1/n}$

$$t_{1/n} = \frac{n^{\alpha-1} - 1}{k(\alpha - 1)} \left(\frac{1}{C_{A0}^{\alpha-1}} \right)$$

► In general, the time required for the concentration to drop to $1/n$ of the initial value, i.e., $C_A = \frac{1}{n} C_{A0}$ at $t = t_{1/n}$