

ESO 205A (P)

Nature and Properties of Materials

Interaction session: 6:30 – 7:20 pm Thursdays



Nilesh Prakash Gurao

Associate Professor

Department of Materials Science and Engineering

Indian Institute of Technology Kanpur

Co-ordinates: FB-408, 6688, 8756562710, npgurao@iitk.ac.in



Module 1

Crystal structure and X-ray diffraction



14 Bravais lattice in 3D

➤ 7 crystal classes

Cubic (P, I, F)

Tetragonal (P, I)

Orthorhombic (P, I, B, F)

Rhombohedral (P)

Hexagonal (P)

Monoclinic (P, B)

Triclinic (P)


➤ 4 type of unit cells

Primitive (P)

Body centered (I)

Base centered (A, B, C)

Face centered (F)



Crystal systems

Minimum Symmetry

Crystal System:	Minimum Symmetry:
Triclinic	No Symmetry
Monoclinic	1 A2
Trigonal	1 A3
Tetragonal	1 A4
Hexagonal	1 A6
Orthorhombic	3 A2
Cubic	4 A3

Crystal System	Axial and Angular Relationships	Bravais Lattice*	No. of lattice points/cell
Cubic	$a = b = c$ $\alpha = \beta = \gamma = 90^\circ$	Simple Cubic (P)	1
		Body Centred Cubic (I)	2
		Face Centred Cubic (F)	4
Tetragonal	$a = b \neq c$ $\alpha = \beta = \gamma = 90^\circ$	Simple Tetragonal (P)	1
		Body Centred Tetragonal (I)	2
Orthorhombic	$a \neq b \neq c$ $\alpha = \beta = \gamma = 90^\circ$	Simple Orthorhombic (P)	1
		Body Centred Orthorhombic (I)	2
		Base Centred Orthorhombic (C)	2
		Face Centred Orthorhombic (F)	4
Hexagonal	$a = b \neq c$ $\alpha = \beta = 90^\circ, \gamma = 120^\circ$	Simple Hexagonal (P)	1
Rhombohedral	$a = b = c$ $\alpha = \beta = \gamma \neq 90^\circ$	Simple Rhombohedral (P)	1
Monoclinic	$a \neq b \neq c$ $\alpha = \gamma = 90^\circ \neq \beta$	Simple Monoclinic (P)	1
		Base Centred Monoclinic (C)	2
Triclinic	$a \neq b \neq c$ $\alpha \neq \beta \neq \gamma \neq 90^\circ$	Simple Triclinic (P)	1



➤ Number of lattice points per unit cell in 3D

Primitive (P): 1


Body centered (I): 2

Base centered (A, B, C): 2

Face centered (F): 4

Prove to your self that only 14 Bravais lattices are possible

Face centered tetragonal = Body Centered Tetragonal





Voids



Octahedral

Tetrahedral

FCC




BCC



Crystallographic directions

- Red arrow $[213]$
- Orange arrow $[222]$ not $2 * [111]$
- Green arrow does not pass through origin so draw a parallel line (dashed) from origin and get $[310]$



Crystallographic planes

- Crystalline materials in 3D have different crystallographic planes
- Different planes have different properties in the same crystal
- Planes are essentially surfaces
- Number of atoms per plane different
- Understanding of planes and the sub dimensional information like number of atoms, and planar packing density important
- Same is true for directions




Miller indices for planes

1. Intercept with X, Y, and Z axis
 2. $(k, 0, 0)$; $(0, l, 0)$ and $(0, 0, m)$
 3. Determine k/a , l/b , m/c , where a , b , c are lattice parameters along X, Y and Z resp.
 4. Determine a/k , b/l , c/m
 5. If fractions then multiply each of these by lowest common multiple (LCM), let say it is N
- Or, if the three numbers have a common factor then divide them with this highest common factor (HCF)

The Miller indices of the plane are

$$\left(\frac{a}{k} N \quad \frac{b}{l} N \quad \frac{c}{m} N \right)$$



X-ray diffraction

➤ Bragg equation


$$n\lambda = 2d \sin\theta$$

n : Order of reflection

d : Plane spacing

$$= \frac{a}{\sqrt{h^2 + k^2 + l^2}}$$

θ : Bragg Angle



Path difference must be integral multiples of the wavelength for constructive interference




Scattering of X-rays by an unit cell

Real space

Crystal Lattice

Crystal structure

Unit cell content




Reciprocal space

Reciprocal Lattice

Diffraction pattern

Structure factor




Reciprocal space

$$a^* = \frac{b \times c}{a \bullet (b \times c)}$$

$$b^* = \frac{c \times a}{a \bullet (b \times c)}$$

$$c^* = \frac{a \times b}{a \bullet (b \times c)}$$

Reciprocal lattice of FCC is BCC and vice versa



Structure factor

- Link crystal structure with diffraction pattern
- Position and intensity of peaks $F_{hkl} = \sum_1^N f_n e^{2\pi i(hu_n + kv_n + lw_n)}$
- Atomic positions decide presence of hkl peak
- SC: (0, 0, 0), so all peaks possible
- BCC: (0, 0, 0) and (0.5, 0.5, 0.5) so only $h+k+l = \text{even}$ peaks possible
- Remember $e^{2n\pi i} = 1$, where n is an integer
- $e^{p\pi i} = -1$, if p is odd



Bravais Lattice	Reflections possibly present	Reflections necessarily absent
Simple	All	None
Body Centered	$(h+k+l)$: Even	$(h+k+l)$: Odd
Face Centered	$h, k,$ and l unmixed i.e. all odd or all even	$h, k,$ and l : mixed



Permitted Reflections

Simple Cubic	$(100), (110), (111), (200), (210), (211), (220), (300), (221) \dots\dots\dots$
BCC	$(110), (200), (211), (220), (310), (222) \dots\dots$
FCC	$(111), (200), (220), (311) \dots\dots$



Physical interpretation

- 100 peak in SC not in BCC and FCC
- Bragg equation derivation
- 100 plane in SC has 1 atom (4×0.25) for a^2 area and 200 plane has zero atom for area of a . $d_{100} = 2d_{200} = a$
- Constructive interference between 100 planes so 100 peak in SC
- In BCC 1 atom for a^2 area for 100 plane and 1 atom per a^2 area for 200 plane. Destructive interference so no 100 peak but 200 peak
- Similar analogy for FCC



➤ From hkl to theta

➤ We can measure $1/10^{\text{th}}$ of a nanometer

➤ In fact we can get a precision of $1/1000^{\text{th}}$ of a nanometer

➤ $s = 1, 2, 3 \dots 6, 8$ for SC (no 7)

➤ $s = 2, 4, 6, 8$ for BCC

➤ $s = 3, 4, 8, 11, 12, 16 \dots$

$$\lambda = 2d \sin \theta$$

$$d = \frac{a}{\sqrt{h^2 + k^2 + l^2}}$$


$$\lambda^2 = \frac{4a^2 \sin^2 \theta}{h^2 + k^2 + l^2}$$

$$(h^2 + k^2 + l^2) = \frac{4a^2}{\lambda^2} \sin^2 \theta$$

$$s = (h^2 + k^2 + l^2) \propto \sin^2 \theta$$




XRD pattern for Cubic Crystals



Intensity of X-ray pattern

- structure factor (F^2)
- polarization factor
- multiplicity factor
- Lorentz factor
- absorption factor
- temperature factor



Module 1 Assignment

- Visit the webpage and take snapshots of SC, BCC and FCC crystals from different views. Mention the plane or direction along which you are acquiring the snapshot.

<https://jeremyberchtold.com/UnitCellVisualizer/>

- Visualize 4 distinct planes such that $h \neq k \neq l$ using this tool

<http://calistry.org/calculate/latticePlanesMillerIndices>

- Index the X-ray diffraction pattern provided in the file. Find the crystal structure and lattice parameter



Stay safe and take care
Get vaccinated

Thank you

